

EXPANSION BEARING ASSEMBLY

FOR STEEL GIRDER (SHOW ON PLANS)

NOTES

FOR STEEL GIRDER BEARINGS:
USE TEMPERATURE SETTING TABLE, RATHER THAN CENTERING BEARINGS BENEATH BEARING STIFFENERS FOR ALL TEMPERATURES.

FOR PRESTRESSED GIRDER BEARINGS:

PLACE BEARINGS AS SHOWN ON THE SUBSTRUCTURE PLAN. PROVIDING ADJUSTMENT FOR SUBSTRUCTURE LOCATION DISCREPANCIES. PLACE EACH GIRDER CENTERED BETWEEN ITS GIVEN BEARINGS.

DESIGNER NOTES

THIS STANDARD SHOULD ONLY BE USED FOR STEEL BEARINGS.

▼ TOP PLATE "A" FOR STEEL GIRDER BEARINGS TO BE DESIGNED TO ACCOUNT FOR THERMAL MOVEMENT AND CONSTRUCTION TOLERANCE. (USE GREATER OF VALUE FROM PROCEDURE BELOW OR SIZE FROM STANDARD 27.08).

PROCEDURE FOR SIZING TOP PLATE "A":


- ANCHOR PLATES IN PRESTRESSED GIRDERS TO BE DESIGNED TO ACCOUNT FOR THERMAL MOVEMENT, GIRDER SHRINKAGE AND CONSTRUCTION TOLERANCE.

PROCEDURE FOR SIZING ANCHOR PLATE:


- 2½ INCHES = ½ TEFLON PLATE LENGTH + THERMAL MOVEMENT (USE 60-5=55 DEGREES)
- + SHRINKAGE = 0.0003'/'
- + 1" CONSTRUCTION TOLEARNCE
- = ½ ANCHOR PLATE LENGTH (DOUBLE THIS FOR PLATE LENGTH)

ACCORDING TO AASHTO, THE LOAD FACTOR FOR TU IS 1.20 FOR DEFORMATIONS. THE PROCEDURE OUTLINED ABOVE SHOULD BE USED WITH A LOAD FACTOR OF 1.0, WITH THE 1" CONSTRUCTION TOLERANCE BEING USED IN LIEU OF THE HIGHER LOAD FACTOR.

THE 90 DEGREE TEMPERATURE RANGE FOR STEEL BEARINGS. BASED ON A 60 DEGREE SETTING TEMPERATURE, IS SLIGHTLY CONSERVATIVE IF THE BEARING OFFSET TABLE IS UTILIZED, SINCE AT 45 DEGREES THE OFFSET WOULD BE ZERO.



FOR DESIGNER INFORMATION, ONLY



SHOWING OFFSET DUE TO EXPANSION OR CONTRACTION

EXPANSION BEARINGS AT PIER

PRESTRESSED GIRDER (CONC. DIAPHS. NOT SHOWN FOR CLARITY) FOR DESIGNER INFORMATION, ONL (DO NOT PUT ON THE PLANS)

STEEL EXPANSION **BEARING DETAILS**



APPROVED: Laura Shadewald

1-23