

Wisconsin Department of Transportation

January 2, 2019

Division of Transportation Systems Development

Bureau of Project Development 4822 Madison Yards Way, 4th Floor South Madison, WI 53705

Telephone: (608) 266-1631 Facsimile (FAX): (608) 266-8459

NOTICE TO ALL CONTRACTORS:

Proposal #24: 1430-00-77, WISC 2019 080

City of Montello, Underwood

Avenue

Park Street to West Street

STH 23

Marquette County

1430-00-87

City of Montello, Underwood

Avenue

Park Street to West Street

STH 23

Marquette County

1430-00-79, WISC 2019 081

City of Montello, Underwood

Avenue

Morningside Court to Park Street

STH 23

Marquette County

1430-00-89

City of Montello, Underwood

Avenue

Morningside Court to Park Street

STH 23

Marquette County

Letting of January 15, 2019

This is Addendum No. 01, which provides for the following:

Special Provisions:

Revised Special Provisions	
Article No.	Description
60	Seeding Mixture Forebay and Spillway, Item SPV.0085.01;
	Seeding Mixture Side Slopes and Berm, Item SPV.0085.02;
	Seeding Mixture Retention Temporary, Item SPV.0085.03.

The responsibility for notifying potential subcontractors and suppliers of these changes remains with the prime contractor.

Sincerely,

Mike Coleman

Proposal Development Specialist Proposal Management Section

ADDENDUM NO. 01 1430-00-77/79/87/89 January 2, 2019

Special Provisions

60. Seeding Mixture Forebay and Spillway, Item SPV.0085.01; Seeding Mixture Side Slopes and Berm, Item SPV.0085.02; Seeding Mixture Retention Temporary, Item SPV.0085.03.

C Construction

Insert the following as the first sentence of the article:

Use Sowing Method A.

Replace sentence two under section titled C Construction with the following:

Add the following to standard spec 630.3.3:

Replace entire section titled **Sowing Method A** with the following:

Method A

(3) Cultipack all areas to be seeded, both before and after broadcasting of seed, using a lightweight lawn roller or similar compaction tool. Use a manual lawn roller or similar tool of sufficient weight to firm the seed bed. Do not use a tractor, 4-wheeler, or other heavy equipment that might over compact the topsoil and subgrade, and/or damage the shape of the spillway, berms or side-slopes.

END OF ADDENDUM