




MUD PLATES NOT SHOWN

1213



SECTION THRU MUD PLATES





FOR CURB OR SIDEWALK ONLY

7. ANCHOR BAR 3/8" DIA. AT 1'-0" CENTERS. BEND AS SHOWN. 8. STIFFENER BAR ⅔" THICK . ½" FILLET WELD ALL AROUND. PLACE AT C/L OF GIRDER AND AT +2'-0" CENTERS BETWEEN GIRDERS.

BEVELED SHIM PLATE ⅔" THICK. ¹∑₁₆" DIA. HOLES FOR NO. 6.

6. ¾" DIA. ERECTION BOLTS. DRILL HOLES IN SHELF PLATE IN THE FIELD.

1. FINGER PLATE. SIZE TO BE DETERMINED BY DESIGN.

2. WEB PLATE. SIZE TO BE DETERMINED BY DESIGN 3. FLANGE PLATE. SIZE TO BE DETERMINED BY DESIGN.

5. ¾" LAMINATED SHIM WITH SLOTTED OPENINGS

9. 7/8" VENT HOLES AT 3'-0" CENTERS.

10. $\rlap{k}_4^{"}$ dia. Adjusting bolt at approx. 4'-0" centers with two $\rlap{k}_6^{"}$ dia. X $\rlap{k}_4^{"}$ plate washers. One on each side of finger plate.

11. MUD PLATE 1/4" THICK

LEGEND

12. ⅔" PLATE. BEND AS SHOWN

13. 3/8" PLATE. BEND AS SHOWN.

14. ¾" PLATE. BEND AS SHOWN. 15. ${}^{}_{\!\!8}{}^{"}$ dia. Studs X $6{}^{'}_{\!\!16}{}^{"}$ long. Weld to plates no. 13 and no. 14.

16. ¾" DIA. BOLT FOR SHIPPING. TACK WELD NUT TO BOTTOM OF PLATE NO. 1.

17. 3" DIA. X 3" DIA. X ½" + 5'-0" SPACING. SLOTTED HOLE ½" X 2¾" IN ONE END OF ANGLE AS SHOWN. FOR BOLT NO. 16.

18. CLOSING PLATE 3/8" CUT AS SHOWN. SEE WELD DETAIL.

19. ¾" PLATE. BEND AS SHOWN.

20. 3/8" PLATE. BEND AS SHOWN

21. 3/8" PLATE. BEND AS SHOWN

22. ³/₄" PLATE. WELD ALL AROUND, ³/₄" FILLET WELD TO PLATES NO. 18, 19, AND 20.

23. %" dia. Studs X $6\%_6"$ long. Bend after weld.

24. ¾" DIA. BOLT WITH SQ. NUT. GREASE FOR EASY REMOVAL ¾" X 1¾" SLOTTED HOLE IN PL. NO. 19. LONG DIMENSION OF HOLE PARALLEL TO C/L OF ROADWAY. TACK WELD NUT TO PLATE NO. 20 + 2'-0" SPA.

25. $\%"_8$ dia. Studs X $6\%_6"$ long. Weld to plate NO. 20.


26. FLANGE PLATE. SAME THICKNESS AS PLATE NO. 3 AND SAME WIDTH AS SHELF PLATE. SHOP BUTT WELD TO PLATE NO. 3.

27. 3/8" CLOSING PLATE. WELD TO PLATES NO. 1 AND NO. 2.

NOTES

REMOVE ANGLE NO. 17 AND ADJUSTING BOLT NO. 10 AFTER VERTICAL AND HORIZONTAL ALIGNMENT IS SECURE IN FIELD. FILL HOLES WITH HOT POURED JOINT SEALER.

IN SOME CASES THE GIRDER FLANGES AND WEB PLATES DO NOT HAVE TO BE CUT TO ACCOMMODATE THE FINGER JOINT SECTION, THE SLAB DEPTH MAY BE UTILIZED EFFECTIVELY.



(14) 8 Ó Ì 3 Ó 445 DETAIL AT PARAPET

3/16


(12)13


DETAIL AT MEDIAN

-


Ó

SHELF PLATE





SECTION THRU SIDEWALK



STANDARD 40.12





